

Adding an IGS Extra

It is an easy job to add an IGS Extra to the existing system.

1. Assemble the support

This is assembled just like the original supports but WITHOUT the Cross Braces. Cross braces are NOT needed on IGS Extra

2. Align the support

Place the Extra Support in line with the existing IGS. It should be placed 80 cm distance from the original Basic system.

The Pot Trays will sit on the unused pegs on the existing Basic system so IGS Extra must connect to that end.

3. Connect Pot Trays

Remove the Outlet Manifold from the Basic system. It can be kept in one piece and re-installed later.

Place the Pot Trays in position – they hook on to the spare tray pegs on Basic system and on to the new support.

4. Connect Gutters

Use the short lengths of PVC pipe – 44mm to connect the gutters. A few turns of PTFE Tape – or a bead of silicon should be placed at each end of this connecting pipe before it is inserted into the Gutters. Hold Gutters wide open when inserting the pipe so the tape or silicon is not wiped off. This will form a seal inside the Gutter and prevent water seeping out. Then take a short length of waterproof Tape and run it across the underside of the gutter – covering the join right across the width. This prevents water seeping through the gap. To finish it off a bead of Silicon can be run across the topside of the join and wiped off so that the gap is fully sealed.

5. Connect Dripper System

IGS Extra Kit contains a full dripper system Plus a connector. It can be simply joined to the existing dripper system using the connector. Remember to use jubilee clamps for water tightness.

